Introduction to TCP/IP My PC's Internet & Gateway

Prof. Jong-Moon Chung

Introduction to TCP/IP

My PC's Internet & Gateway

- 1. My PC's Internet Setup
 - IP Address, Subnet Mask, Default Gateway, DNS Server
- 2. Automatic Internet Setup using DHCP
 - DHCP (Dynamic Host Config. Protocol)
- 3. IP Gateway/Router Configuration
 - IP Address Assignment
 - Subnet & Subnet Mask Setup
- 4. IP Routing Table


Introduction to TCP/IP

My PC's Internet & Gateway


My PC's Internet Setup

IPv4 Network Connection Setup

Control Panel




Network Connection




IPv4 Network Connection Setup


DHCP (Dynamic Host Configuration Protocol)




IPv4 Network Connection Setup





IPv4 Network Connection Setup





IPv4 Network Connection Setup





IPv4 Network Connection Setup

IP Address of the PC

- Decimal form
- 10100101.10000100.01111110.10011111
- Binary form

IP Address Assignments

- Computer or Smartphone may have multiple Interfaces and therefore may need multiple IP addresses (one IP address for each Interface)
- Smartphone example



Samsung Galaxy S7 Edge

IPv4 Network Connection Setup

IP Address Assignments


- Smartphone Example
 - Smartphones need multiple IP addresses for multiple interfaces
 - Mobile Communication
 - √ 2G (GSM)
 - √ 3G (UMTS, TD-SCDMA)
 - √ 4G (LTE FDD, TDD)
 - Wi-Fi
 - IEEE 802.11 a/b/g/n/ac (2.4, 5 GHz)
 - · Bluetooth v4.2

Subnet Mask

- Internet is divided into Subnets, and Subnets are divided into smaller Subnets
- Subnet Mask is based on the size of the Subnet that the Client (PC) is connected to
- IPv4 Subnet Mask is formed by 32 bits
 - 1s or 0s in a sequence from Left (MSB) to Right (LSB)
 - ✓ MSB: Most Significant Bit
 - ✓ LSB: Least Significant Bit


IPv4 Network Connection Setup

- Subnet Mask is used to mask (filter) the IP address (of IP packets) to easily determine if the packet belongs to this subnet or not
- 255.255.252.0 =



- 10 zeros Subnet Mask can be used to find the Subnet size
- $-2^{10} = 1,024$ IP addresses are on this subnet
 - But not all addresses can be used for Clients (PCs) → Why?
 - This will be explained in the following lectures


Default Gateway



- Default Gateway is the dedicated Internet Router that will send and receive all Internet IP packets for this PC
- PC will access the Internet (i.e., send and receive all IP packets) through this Gateway


IPv4 Network Connection Setup

DNS (Domain Name Server)



- DNS is a server that converts hostnames in to IP addresses
- Hostname examples
 - · E-mail address
 - ???@gmail.com
 - · Website address
 - · www.facebook.com

DNS (Domain Name Server)



- DNS operation example
 - · Website address



- IP address
- Preferred is the main
- Alternate is the backup

Introduction to TCP/IP

My PC's Internet & Gateway

- 1. My PC's Internet Setup
 - IP Address, Subnet Mask, Default Gateway, DNS Server
- 2. Automatic Internet Setup using DHCP
 - **DHCP (Dynamic Host Config. Protocol)**
- 3. IP Gateway/Router Configuration
 - **IP Address Assignment**
 - Subnet & Subnet Mask Setup
- 4. IP Routing Table